

EX250

EX300

EX350



CONTROL CONSOLE

FULL CONTROL.

WIRELESS CONTROL

7" LCD DISPLAY TOUCH SCREEN

The EX control console allows for full camera control and pan as well as: Gain, Iris, White Balance, Gamma, Shutter, Saturation, Detail, Color Balance, Frame Rate, Shutter, ND filters, Head Tuning, Axis Speed, Focus, Zoom and much more at your fingertips.

F12 CONTROLS

ERGONOMIC FOCUS, IRIS AND ZOOM CONTROLS ALLOW FOR A COMFORTABLE HAND POSITION FOR ACCURATE ON DEMAND CONTROL.

BPU30 BATTERY

OPTIMAL BATTERY POWERS THE CONSOLE FOR 8 HOURS. AC ADAPTER WHEN USED WILL ALSO CHARGE BATTERY.

7" TOUCH SCREEN

ACCESS MENUS, SETTINGS AND CAMERA CONTROL.



5 X ROTARY CONTROL SWITCHES

QUICKLY ADJUST VARIOUS SETTINGS ON THE FLY BY SIMPLY TOGGING LEFT OR RIGHT AND PRESSING TO CONFIRM.

The EX Control Console, a full ergonomic console feels great on the desk, in your lap or handheld for quick relocation setup. Our intuitive 7" on-screen user interface maximized for control of system settings and user preferences. An integrated dimmable LED light under console provides soft light to highlight shot notes within handle recess.



ADJUSTABLE **1** LONG RANGE RADIO ((•))
WATT 2 MILE RANGE (LOS)

The console has an internal 1w, dual band, control transceiver for wireless connection to the head for on demand control of Camera, RCP, Joy-Stick Movement, settings and much more.




The EX heads and the EX Joystick Console have internal wireless modem modules. Power and frequency is selected via the joystick console user interface. If the system detects a cabled ethernet connection the modem automatically turns off.

COMMUNICATION.

EX CONSOLE LAYOUT

1. Focus control
2. Zoom rocker
3. Iris control
4. 5 x rotary control switches
5. 7" LCD display. Control and setup menus
6. Pan/Tilt/Roll joystick



1. BPU battery dock (auto charger)
2. Power input (24vdc)
3. RS485 Serial Port
4. Power Button
5. RJ45 Ethernet (to head)
6. Spare

